



Find Your Paradise

Thank you for your purchase!

Your efin package includes:

Battery box (waterproof)

Remote control

Charger

Efin

Magnetic safety leash

Waterproof phone bag (For remote)

Straps

Mounting brackets (for permanent installations)

The efin has 4 speeds and is controlled with the wireless remote.

Press the up button to increase speed, press the down button to decrease speed. Press the stop button to stop. The button on the right does not have any function. Remote is not waterproof. Remote should come paired to the battery box. If it ever needs to be repaired, connect the efin and the magnetic safety switch and within a few seconds press and hold the stop button and up button on the remote, you should hear a beep when paired.

Charging time is 6-8 hours. Light is red when charging and turns green when fully charged. Batteries come charged, but it is recommended to fully charge before each use.

One charge can last you over 6 hours at lower speeds and 2-3 hours at top speeds.

Can get up to over 5mph depending on board, rider and conditions. Battery does not have a charge level indicator.

Efin mounts into standard fin box just like a regular center fin. The Battery box goes on top of the deck and should be strapped down. The efin is not intended for surf or whitewater use.

The short leash has a magnetic safety switch. This must be attached to the battery box for it to work. Be sure to test that when the magnetic connection is broken, the efin stops.

Battery is rated for 1500 cycles - recommended to charge at least once every 3 months when not being used. Saltwater use is ok - be sure to rinse with fresh clean water after each use as you should with all your equipment. If the efin gets grass, seaweed, or other debris caught in it. Be sure to disconnect the efin from the battery before removing debris. Never place fingers or body parts near the propeller. It is very sharp and can cause injury. Efin should only be used by adults.

90-day warranty from date of purchase.

By purchasing and/or using a board or other equipment, you affirm that you are aware that stand up paddle boarding, surfing and foiling has inherent risks which may result or be associated with serious injury or death. You personally assume all risks involving the use thereof including, but not limited to, the risk of personal injury or death to yourself and others, as well as potential damage to property while using a paddle board, whether negligent, intentional, foreseen or unforeseen.

By purchasing and/or using the paddle board, you irrevocably and unconditionally agree to indemnify, defend and save harmless, release and promise to not bring a claim of any nature against, Tamarindo Board Co. (KAKA Enterprises, LLC) , or it's dealers.